

SUPERIOR SAFE

Contact:
info@telecontrol.tv
for DE – ES – FR – GR – HR – PT
instructions



Impostazioni di fabbrica:
Factory Settings:
Codice TV TV Code 0181
Codice SAT SAT Code 1914

ITALIANO

RICERCA RAPIDA PER MARCA:

TV	SAT
1 Hitachi	CanalSat
2 JVC	Digital
3 LG	Foxtel
4 Panasonic	Humax
5 Philips	MultiChoice
6 Pioneer	Philips
7 Samsung	Pioneer
8 Sharp	SKY
9 Sony	TechniSat
0 Toshiba	Sky Deutschland

- 1) Posizionarsi con il telecomando davanti all'apparecchio che si vuole controllare verificando che sia acceso.
- 2) Tenere premuti il tasto del banco di memoria ("TV" o "SAT") e "MENU" finché il LED si accende (circa 3 secondi).

WWW.SUPERIOR-ELECTRONICS.COM

SELF-LEARNING FUNCTION:

- 1) Position the original remote control at a distance of 3-5 cm from the Superior "Safe" model, with the infrared LEDs of the two remote controls facing each other.
- 2) Select the memory bank ("TV" or "SAT") on which the function is to be used. Hold down the hidden key found above "INFO", in order to activate the self-learning mode.
- 3) Press the key of the original remote control that is to be copied. The LED of the Superior "Safe" model will begin to blink slowly.
- 4) Press the key of the Superior "Safe" remote control on which the key of the original remote control is to be memorised. The LED of the Superior "Safe" model will go on again, confirming the operation.
- 5) Repeat steps 3-4 for any additional keys to be copied.

NOTE: If necessary, any key that has been copied can be memorised over again.

- 6) Press the hidden key once again to exit the self-learning mode.
- 7) If the LED of the Superior "Safe" remote control should blink twice during the learning procedure and unexpectedly exit the mode, there may be a problem of memory or compatibility with the original remote control. It may be necessary to cancel some of the keys memorised on one of the two memory banks ("TV" or "SAT") in order to continue.

Cancelling a memorised key:

- 1) Hold down the key of the memory bank ("TV" or "SAT") and the "MENU" key, until the LED goes on (approximately 3 seconds).
- 2) Press the sequence of numbered keys "9-9-0-0". The LED will give 3 rapid blinks to confirm the reset operation.
- 3) Press the key that is to be cancelled. The LED will blink twice, confirming the operation, and then go back on again.
- 4) Repeat step 3 for any other function to be removed.
- 5) To exit the cancellation mode, press "TV" or "SAT".

Logik	1154 2204 1864 3544
LogiSat	3504 3524 2184 3324
Logix	0544 0614
Lorenzen	0794 1184 0164 0054
	0274 2184
Lupus	2274
Luxor	2204
Lowry	2304
Luxon	2164
M vision	1764 2884 3224
M7	3414
Macab	0394 0444 0424
Madriell	0304 0984
Majestic	3464 3594 3544
Manista	0344 0054
Manhattan	0644 2304 0544 3094 0704
Marantz	1514 0464 2294 2054 2064
Marusys	3514 3724
Mascom	2394 3464
Maspro	0344 0094 0194
Master's	2284
Matazi	0634
Matv	0094 2744 1334 0194 934
	2204 0234
Maximum	0814 1314 1014 2074
Mega	0964
Megastar	0154 0444 0424
Mediastar	2254
Mediastar	0154 0444 0424 2434
Mediastar	3494 3474 3234 1054 3454
Mediastar	0224 0234
Mediastar	0814
Mediastar	0994 0794 0344 0564 0054
Mediastar	0614 1414 2004 1314 2274
Mediastar	2804 0654 3504 0274
Mediastar	1334 1014 0374 2184
Medion	0344
Mega	0104 0234
Megasat	1344 1824 3524
	0374 0274 2204 3464
Meletronic	0334
Meo	3324
Mercury	3674
Metronic	0344 2614 2254 1114 1144
	4004 2684 0054 2474 3234
	2204 1524 2014 1344 3464
	2324 2094 2074 1584
Metz	0394 0194
MICO	1874 2094
Mico	0344 1184 3264 3524 3504
Mico electronic	0344 3264 3524
Mico Technology	0344

Cancelling all of the keys memorised on one of the memory banks:

- 1) Hold down the key of the memory bank ("TV" or "SAT") and the "MENU" key, until the LED goes on (approximately 3 seconds).
- 2) Press the sequence of numbered keys "9-9-0-0". The LED will blink twice, slowly, to confirm the cancellation.

Cancelling all of the keys memorised on all the memory banks:

- 1) Hold down the key of a memory bank ("TV" or "SAT") and the "MENU" key until the LED turns on (approximately 3 seconds).
- 2) Press the sequence of numbered keys "9-9-0-0". The LED will give 3 rapid blinks to confirm the reset operation.

RESTORING THE FACTORY SETTINGS:

- 1) Hold down the key of a memory bank ("TV" or "SAT") and the "MENU" key, until the LED goes on (approximately 3 seconds).
- 2) Press the sequence of numbered keys "9-9-0-0". The LED will give 3 rapid blinks to confirm the reset operation.

AMT	0344
Anglo	0344
Ankstar	2274 0344 1114
AntSat	0544 0644
Ansonic	3294
Antiference	2204
AnySat	2654
Apollo	2304
Apra	0204 0014
Area	1714
Argos	3384
Arcon	0564 1114 0054 0614
Arcion	0054
Armstrong	2254 0104 0234
Arnion	1204 0704
ASA	0794 0274 0374
Asat	0104 0234
ASCI	1314 0204 1014
Asda	2204
ASLF	0344

IT – LISTA CODICI SAT/DTT EN – SAT/DTT CODES LIST

@sat	1204 0704
@Sky	1314 1014
Absat	1274 0344 0774
Acoustic Solutions	2204
ADB	0304 2364 1454 1074 1624
Akira	1384 1484 0994 2424 3484
Adcom	0104 0234
AEG	3464 5234
AGK	2644
Agora	2204
Akris	1524 2094 3524 3594
Akura	0104 0234 3574
Akura	3524 3464
Alba	2304 0344 1154 2084 2874
	2204 1524 3384
	0104 0544 0564 0234
Allsat	2274
Allsonic	0344
Altech	2274
Alvion	0994 0654 1014
Alpha	0104 0234
Amino	2454
Amtronica	0344
Ampere	0054
Altech UEC	2054 2344 2064 2294
Amstrad	0434 2634 0824 2844 2254
	0344 0054 0754 0944 1644
	0544 1544 2664 3614
	1794 3344
AMT	2444 3524 2094
Anglo	0344
Best Boy	2094 2464 3444 3544 3294
Restar	2254
AntSat	0544 0644
Ansonic	3294
Antiference	2204
AnySat	2654
Apollo	2304
Apra	0204 0014
Area	1714
Argos	3384
Arcon	0564 1114 0054 0614
Arcion	0054
Armstrong	2254 0104 0234
Arnion	1204 0704
ASA	0794 0274 0374
Asat	0104 0234
ASCI	1314 0204 1014
Asda	2204
ASLF	0344

si accenda (circa 3 secondi).

- 3) Premere la sequenza di tasti numerici "9-9-8- (0-9)" (l'ultima cifra deve essere scelta dalla tabella iniziale, in base al modello di accensione ed alla marca cercata).
- Verrà inviato ciclicamente un segnale per spegnere il dispositivo intervallato da un lampeggio del LED.
- 4) Quando il dispositivo si spegnerà, premere il tasto "OK" per confermare il codice ed interrompere la ricerca.
- 5) Verificare che il telecomando funzioni regolarmente, altrimenti ripetere la procedura dal punto 2.

RICERCA RAPIDA:

- Cercare il codice di programmazione per il proprio dispositivo dalla lista alla fine di questo manuale prima di procedere con il primo passaggio.
- 1) Posizionarsi con il telecomando davanti all'apparecchio che si vuole controllare verificando che sia acceso.
 - 2) Tenere premuti il tasto del banco di memoria ("TV" o "SAT") e "MENU" finché il LED si accenda (circa 3 secondi) per entrare in modalità di inserimento codice.
 - 3) Inserire il codice a 4 cifre scelto.
 - 4) Il LED si spegnerà a conferma dell'avvenuta programmazione. Nel caso in cui la procedura non sia andata a buon fine, il LED emetterà 2 lampeggi brevi e resterà acceso.
 - 5) Verificare che il telecomando funzioni regolarmente, altrimenti ripetere la procedura dal punto 3, inserendo un codice diverso.
- NOTA:** Il telecomando uscirà automaticamente dalla modalità di programmazione dopo circa 15 secondi se non dovesse essere premuto alcun tasto.

RICERCA AUTOMATICA:

ATTENZIONE: Da utilizzare solo se non sia stato possibile trovare il codice specifico tramite le due ricerche rapide.

- 1) Posizionarsi con il telecomando davanti all'apparecchio che si vuole controllare

si accenda (circa 3 secondi).

- 2) Tenere premuti il tasto del banco di memoria ("TV" o "SAT") e "MENU" finché il LED si accenda (circa 3 secondi).
- 3) Premere il tasto di accensione/spegnimento per avviare la ricerca automatica del codice. Verrà inviato ciclicamente un segnale per spegnere il dispositivo intervallato da due lampeggi del LED.
- NOTA:** Per tornare ad un codice precedente, si potrà cambiare il verso della ricerca premendo il tasto "CH".
- Per riprendere il verso crescente, premere il tasto "CH".
- 4) Quando il dispositivo si spegnerà, premere il tasto "OK" per confermare il codice ed interrompere la ricerca.
- 5) Verificare che il telecomando funzioni regolarmente, altrimenti ripetere la procedura dal punto 2.

CONDIVISIONE TASTI "VOLUME" ("VOL-/VOL+/MUTE"):

Questa funzione permette di condividere i tasti "VOL-/VOL+/MUTE" del banco di memoria "TV" con il banco di memoria "SAT", sovrascrivendo gli stessi tasti di quest'ultimo. Ciò permetterà di comandare i tasti "VOLUME" della TV anche quando è selezionato il codice "SAT".

- 1) Tenere premuti i tasti "SAT" e "MENU" finché il LED si accenda (circa 3 secondi).
- 2) Premere la sequenza di tasti numerici "9-1-0-0". Il LED lampeggerà due volte a conferma e resterà acceso.
- 3) Premere il tasto "TV". Il LED lampeggerà due volte e si spegnerà a conferma del completamento della procedura.

Per interrompere la condivisione dei tasti "VOLUME":

- 1) Tenere premuti i tasti "SAT" e "MENU" finché il LED si accenda (circa 3 secondi).
- 2) Premere la sequenza di tasti numerici "9-1-1-0". Il LED lampeggerà due volte e si spegnerà a conferma del completamento della procedura.

PER SBLOCCARE IL CODICE:

Selezionare il banco di memoria desiderato ("TV" o "SAT") e, successivamente, tenere premuto il tasto "INFO" per circa 7 secondi. Il LED lampeggerà tre volte e si spegnerà a conferma del completamento della procedura.

Funzione di sbloccaggio del codice:

Selezionare il banco di memoria desiderato ("TV" o "SAT") e, successivamente, tenere premuto il tasto "INFO" per circa 7 secondi. Il LED lampeggerà tre volte e si spegnerà a conferma del completamento della procedura.

Funzione di autoapprendimento:

- 1) Posizionare il telecomando originale ed il Superior "Safe" ad una distanza di 3-5 cm con il LED ad infrarossi l'uno di fronte all'altro.
- 2) Selezionare il banco di memoria ("TV" o "SAT") sul quale si desidera utilizzare la funzione. Tenere premuto il tasto nascosto sopra "INFO" finché il LED si accenda (circa 3 secondi), per attivare la modalità di autoapprendimento.
- 3) Premere il tasto del telecomando originale che si desidera apprendere. Il LED del Superior "Safe" comincerà a lampeggiare lentamente.
- 4) Premere il tasto del Superior "Safe" sul quale si desidera memorizzare quello del telecomando originale. Il LED del Superior "Safe" si accenderà nuovamente a conferma.
- 5) Ripetere i punti 3-4 per ogni ulteriore tasto da apprendere.

NOTA: Ogni tasto appreso, se necessario, potrà essere direttamente sovrascritto.

3) Premere nuovamente il tasto nascosto per uscire dalla modalità di autoapprendimento.

NOTA: Se durante l'apprendimento il LED del Superior "Safe" dovesse lampeggiare due volte, uscendo in modo inaspettato dalla procedura, potrebbe essersi verificato un problema di memoria/compatibilità con l'originale. Potrebbe essere necessario eliminare alcuni

tasti memorizzati su uno dei due banchi di memoria ("TV" o "SAT") per poter proseguire.

Eliminare un tasto memorizzato:

- 1) Tenere premuti il tasto del banco di memoria ("TV" o "SAT") e "MENU" finché il LED si accenda (circa 3 secondi).
- 2) Premere la sequenza di tasti numerici "9-9-9-0". Il LED resterà acceso.
- 3) Premere il tasto che si desidera eliminare. Il LED lampeggerà due volte a conferma e si accenderà nuovamente.
- 4) Ripetere il punto 3 per ogni altra funzione da rimuovere.
- 5) Per uscire dalla modalità di eliminazione, premere "TV" o "SAT".

Eliminare tutti i tasti memorizzati su uno dei banchi di memoria:

- 1) Tenere premuti il tasto del banco di memoria ("TV" o "SAT") e "MENU" finché il LED si accenda (circa 3 secondi).
- 2) Premere la sequenza di tasti numerici "9-9-9-1". Il LED lampeggerà lentamente due volte per confermare l'avvenuta eliminazione.

Eliminare tutti i tasti memorizzati su tutti i banchi di memoria:

- 1) Tenere premuti il tasto di un banco di memoria ("TV" o "SAT") e "MENU" finché il LED si accenda (circa 3 secondi).
- 2) Premere la sequenza di tasti numerici "9-9-9-5". Il LED lampeggerà lentamente due volte per confermare l'avvenuta eliminazione.

RIPRISTINARE LE IMPOSTAZIONI DI FABBRICA:

- 1) Tenere premuti il tasto di un banco di memoria ("TV" o "SAT") e "MENU" finché il LED si accenda (circa 3 secondi).
- 2) Premere la sequenza di tasti numerici "9-9-0-0". Il LED lampeggerà rapidamente 3 volte per confermare il ripristino.

ENGLISH

RAPID SEARCH BY BRAND:

TV	SAT
1 Hitachi	CanalSat
2 JVC	Digital
3 LG	Foxtel
4 Panasonic	Humax
5 Philips	MultiChoice
6 Pioneer	Philips
7 Samsung	Pioneer
8 Sharp	SKY
9 Sony	TechniSat
0 Toshiba	Sky Deutschland

- 1) Position the remote control in front of the device to be controlled, making sure that the device is turned on.
- 2) Hold down the key for the memory bank ("TV" or "SAT") and the "MENU" key, until the LED lights up (approximately 3 seconds).
- 3) Press the on/off key, in order to start the automatic search for the code.

A series of signals to turn the device off, each separated by two blinks of the LED, will be sent out.

- 4) When the device does turn itself off, press the "OK" key to confirm the code and stop the search.
- 5) Make sure that the remote control is operating properly, otherwise repeat the procedure starting from step 2.

RAPID SEARCH:

Before proceeding with the first step, find the programming code for your device from the list at the end of this manual.

- 1) Position the remote control in front of the device to be controlled, making sure that the device is turned on.
- 2) Hold down the key for the memory bank ("TV" or "SAT") and the "MENU" key, until the LED goes on (approximately 3 seconds), in order to activate the mode for entering codes.
- 3) Enter the 4-digit code selected.
- 4) The LED will turn itself off, confirming that the code has been programmed. If the procedure has not been successful, then the LED will give 2 short blinks and stay on.
- 3) In this case repeat the operation, starting from step 3.
- 5) Make sure that the remote control is operating properly, otherwise repeat the procedure starting from point 3 and using a different code.

NOTE: If no key is pressed, then the remote control will automatically exit the programming mode after approximately 15 seconds.

AUTOMATIC SEARCH:

ATTENTION: To be carried out only if the proper code cannot be found using the two types of rapid search.

- 1) Position the remote control in front of the device to be controlled, making sure that the device is turned on.
- 2) Hold down the key for the memory bank ("TV" or "SAT") and the "MENU" key, until the LED lights up (approximately 3 seconds).
- 3) Press the on/off key, in order to start the automatic search for the code.

A series of signals to turn the device off, each separated by two blinks of the LED, will be sent out.

- 4) When the device turns itself off, press the "OK" key to confirm the code and stop the search.

5) Make sure that the remote control is operating properly, otherwise repeat the procedure from point 2.

SHARING OF THE "VOLUME" KEYS ("VOL-/VOL+/MUTE"):

This function makes it possible to share the "VOL-/VOL+/MUTE" keys of the "TV" memory bank with the "SAT" memory bank by superimposing the "TV" volume keys on the "SAT" ones.

In this way, the "VOLUME" keys of the TV can be adjusted even when the "SAT" code has been selected.

- 1) Hold the "SAT" and "MENU" keys down, until the LED goes on (approximately 3 seconds).
- 2) Press the sequence of numbered keys "9-1-1-0". The LED will blink twice and turn itself off, confirming completion of the procedure.
- 3) Press the "TV" key. The LED will blink twice and turn itself off, confirming completion of the procedure.

To interrupt the sharing of the "VOLUME" keys:

- 1) Hold the "SAT" and "MENU" keys down, until the LED turns on (approximately 3 seconds).
- 2) Press the sequence of numbered keys "9-1-1-0". The LED will blink twice and turn itself off, confirming completion of the procedure.

LOCKING THE CODE:

To keep the programmed code from being modified, select the memory bank desired ("TV" or "SAT") and press down the "OK" key for approximately 7 seconds. The LED will blink three times and turn itself off, confirming completion of the procedure.

Select the memory bank desired ("TV" or "SAT") and press down the "INFO" key for approximately 7 seconds. The LED will blink three times and turn itself off, confirming completion of the procedure.

AsCom	0444 0424
Aison	2384 1084
Astra	0344 1544 0584
Astratec	2744 1934
Astell	2144 3294
Astro	0064 0094 2804 2274 0314
Bubu Sat	0754 0664 0674 0104 0154
Acoustic Solutions	0194 2184 0294 0474
ADB	0304 2364
Akira	1384 1484 0994 2424 3484
Adcom	0104 0234
AEG	3464 5234
AGK	2644
Agora	2204
Akris	1524 2094 3524 3594
Akura	0104 0234 3574
Akura	3524 3464
Alba	2304 0344 1154 2084 2874
	2204 1524 3384
	0104 0544 0564 0234
Allsat	2274
Allsonic	0344
Altech	2274
Alvion	0994 0654 1014
Alpha	0104 0234
Amino	2454
Amtronica	0344
Ampere	0054
Altech UEC	2054 2344 2064 2294
Amstrad	0434 2634 0824 2844 2254
	0344 0054 0754 0944 1644
	0544 1544 2664 3614
	1794 3344
AMT	2444 3524 2094
Anglo	0344
Best Boy	2094 2464 3444 3544 3294
Restar	2254
AntSat	0544 0644
Ansonic	3294
Antiference	2204
AnySat	2654
Apollo	2304
Apra	0204 0014
Area	1714
Argos	3384
Arcon	0564 1114 0054 0614
Arcion	0054
Armstrong	2254 0104 0234

